EMpower
Activation Manual

1. Start EMpower

- Click the EMpower shortcut icon (Windows / Mac Operating System)

- In Linux, run the empower.sh script in the EMpower installation directory
- The text "Unlicensed" will appear at the bottom of the EMpower window

2. Click Field QC or Manage buttons

3. Complete the information

- ○ Enter the **'Activation Code'** (license activation card)

4. After typing the activation code correctly the icon changes from ❌

red check mark to a ✔ green check

💡 **Recommendation**:

Write the Computer Name on the back of the card using a permanent marker.

🎀 **Remember:**

Keep the EMpower license card in a safe place, this information will be necessary if you need to re-install EMpower in the future.

Front

EMpower 2

PHOENIX GEOPHYSICS

Scratch gray area to get your Activation Code.

activationCode

Back

⚠️ Save this card

This Activation Code is permanently linked to EMpower on

_____

Computer Name

⬇️ **EMpower** phxgeo.ca/empower/Latest
**Manuals** phxgeo.ca/manuals/Latest

❗ *Transferring the EMpower license to another computer is not supported.*

5. Error messages

If one of the following error messages are shown, check the internet connection and try again

Activation Required - EMpower ✕

EMpower has not been activated.

To activate EMpower:

1. Enter your first and last names in their respective fields below, along with your email address, company name, country.

2. Enter the Activation Code found on the license card provided by Phoenix

Service unavailable - EMpower ✕

⚠ Phoenix servers could not process your license request. Check the entered activation code and try again

OK

Run diagnostics - EMpower ✕

❓ Would you like to print a diagnostics report?

Yes   No

***Please check out the FAQs** https://phoenixgeophysics.freshdesk.com/*
***Or email us at:** support@phoenix-geophysics.com*